

**Ronco Item No** : 79-455-XX ( 08, 09, 10, 11 )

Brand :  **PVC PLUS**


Item Code : **79-455**

Description : PVC Co-Polymer Blend Cold Resistant Glove  
Triple Dipped, Textured Grip, 12" Gauntlet  
Yellow Cashmere Fleece Liner

Colour : Sky Blue




Mechanical ratings : CE EN388: 4121 ( abrasion, cut, tear, puncture )  
Chemical ratings: : CE EN374: AJKL (Methanol, n-Heptane, Sodium hydroxide 40%)



Specification	Size :	M	L	XL	2X-L
		8	9	10	11
	Item Number :	79-455-08	79-455-09	79-455-10	79-455-11
	Length : (mm) ± 10 mm	300	300	300	300
	Palm Width: (mm) ± 5 mm	112	120	128	135

Packaging : 12 pairs x 6 bags = 72 pairs per case

Applications : **Ronco Integra 79-455** is a premium cold and chemical protective glove made from a special blend of polymer materials to enhance performance. It is more flexible, softer and more hand-forming than standard triple dipped PVC gloves of the same calibre. The gloves provide excellent resistance to oils, fats, solvents and a variety of other chemicals including acids. Applications include:

- Cold storage and freezer handling (up to -30°C)
- Petrochemical and oil refinery
- Chemical processing
- Cold food processing
- Fisheries
- Cleaning, degreasing and plant maintenance

Product Features :

- Triple PVC dip provides excellent protective thickness against oils, greases, solvents, acids and a variety of other chemicals.
- The glove's special co-polymer formulation enhances flexibility for prolonged wear and minimal hand fatigue
- Yellow cashmere fleece liner provides cold protection up to -30°C
- The glove remains very soft and flexible under cold applications
- Its enhanced palm and finger texture provides excellent dry and wet grip
- Excellent abrasion resistance, suitable for heavy labour work

Storage & Handling : Store in original packaging at room temperature under roof away from direct sunlight and moisture. Wash in cool or warm water. Hang to dry.

Special Notes : Although reasonable care has been taken in the preparation of this document, no warranties are extended and no liability is assumed. The information is solely provided as a general guideline for product use and care. It is up to end-users to make their own determination as to the suitability of the product for their own intended purpose(s).